

# Manual



# Lightning

**English Rev. 1.0 Stand: April 2014**

Please read the manual before you fly your new U-Turn LIGHTNING

Copyright ©

2014 by U-Turn GmbH, all right preserved. No part of this publication may be reproduced or developed further on in any way without written approval of the U-Turn GmbH

Text: Stefan Preuss and Daniela Martin

Text and Graphics: Ernst Strobl

All technical details in this manual have been carefully checked by U-Turn. However we like to mention that we don't take any liability for possible mistakes, neither in legal responsibility, nor in liability cases that derive from mistakable details. We preserve the right to change this manual in any way to achieve technical improvements.

# Contents

<b>U-Turn your airline</b>	Page 1
<b>Thank you</b>	Page 2
<b>The U-Turn LIGHTNING</b>	Page 3-4
- Usage	Page 4
- Motorised Paragliding	Page 4
- Winching	Page 4
<b>Safety Precautions</b>	Page 5
<b>Baseline and brakeline adjustment</b>	Page 6
<b>General description</b>	Page 6
- Lines and Risers	Page 6
- Risers	Page 7
- Speed System	Page 8
- Operation	Page 8
<b>The Flight</b>	Page 9
- Take off	Page 9
- Turning	Page 9
- Active Flying	Page 10
- Landing	Page 10
<b>Rapid Descent</b>	Page 11
- „Big Ears“	Page 11
- B-Stall	Page 12
<b>Advanced Handling</b>	Page 12
- Spiral Dive	Page 12
- Wingover	Page 12
- Full Frontal	Page 12
- Collapses	Page 13
- How to avoid collapses	Page 13
- Deep Stall	Page 14
- Fullstall	Page 14
- Negativ Turn	Page 15
- Emergency Piloting	Page 15
- Transport and storage	Page 15
<b>Maintenance and Care</b>	Page 16
<b>Nature and environment friendly behavior</b>	Page 16
<b>Flight accessories</b>	Page 17

- Harness	Page 17
- Suitable Rescue System	Page 17
<b>Assumption of Risk</b>	Page 18
<b>Liability claim and renouncement of exclusion</b>	Page 18
<b>Safety Advice and Liability</b>	Page 18
<b>Release of Liability / Renouncement of Entitlement</b>	Page 19
<b>Technical Data U-Turn LIGHTNING</b>	Page 20
<b>Softlink-info</b>	Page 21
<b>Table of area loading and Color-Info</b>	Page 22
<b>Material Info U-Turn LIGHTNING</b>	Page 22
<b>Material List U-Turn LIGHTNING</b>	Page 23
<b>Leinencode-Info</b>	Page 24
<b>Lineplan</b>	Page 25
<b>Certification U-Turn LIGHTNING S</b>	Page 26 - 28
<b>Certification U-Turn LIGHTNING S/M</b>	Page 29 -31
<b>Certification U-Turn LIGHTNING M</b>	Page 32 - 34
<b>Certification U-Turn LIGHTNING L</b>	Page 35 - 37
<b>Instruction leaflet of repairs and 2 annual check</b>	Page 38
<b>Line Order Sheet</b>	Page 39
<b>Business Replay Card</b>	Page 40
<b>Maintenance log</b>	Page 41
- Topic of the inspec	Page 42
- Who may inspect/ test?	Page 42
- Individual personal prerequisites for the inspections	Page 42
- Necessary equipment the following steps are to be taken in	Page 42
<b>During the inspection the following steps are to be taken in</b>	Page 43
- Positive indentification of the device	Page 43
- Inspection of the rerve parachute	Page 43
- Testing of the topsail, undersaild, seams, reserve parachute of	Page 43
- Holes and tears	Page 43
- Abrasion and deformaties	Page 43
- Testing of the rips	Page 43
- Check of the tear resistance	Page 44
- Porositycheck of the canopy	Page 44
- Connection parts	Page 44
- Lines	Page 45
- Check of the line length and line attachments	Page 45

- Occasional check of trim and adjustment	Page 46
- Description of the materials and technical data	Page 46
- Miscellaneous	Page 46
- <b>Completed check very important</b>	Page 47

## **U-Turn your airline**

U-Turn GmbH was incorporated in 2002 by Thomas Vosseler and Ernst Strobl after some years of market analysis. Vosseler, hobby-pilot and successful entrepreneur in the computer and software business, is the sales and marketing specialist, while Strobl is in charge as Head of Development.

The company grew fast in Germany and Austria, and in 2004 the international distribution started. Today U-Turn gliders and related products such as rescues, helmets or flight-wear are available all over the world. The company`s headquarter is in Tuningen near the Black Forest and 30 minutes by car to the lake Constance.

U-Turn paragliders are in a class of their own. U-Turn doesn`t compromise on safety, and uses the best quality components and hallmark flight characteristics. Congratulation on you purchase of U-Turn glider, as it is the brand for those who appreciate the difference.

The laws of physics are well defined. We aspire to achieve to possible within the framework of its laws. We admit this is ambitious but you will always find U-Turn at the cutting edge of technology. As Oscar Wilde once said in this very British understatement: "His taste is very basics; only always the best is good enough." The U-Turn team embodies this attitude; "We always want to deliver the best possible glider". Nothing more and most certainly nothing less. U-Turn staff takes notice of its customer wishes, so we appreciate any comments or feedback!

Please feel free to contact your competence center or U-Turn directly for any advice or direction.

## Thank you

The U-Turn team would like to congratulate you on the purchase of your new U-Turn paraglider. You have made an excellent choice. We wish you long and enjoyable flights and many happy landings with your U-Turn LIGHTNING.

The research and Development team at U-Turn can proudly look back at many successful years in the flight sport industry. Our own concepts not only meet but exceed industry standards. The combination between the latest computer based technology and the know-how of experienced test pilots and professional competition pilots provides an excellent basis for quality. We certainly keep our customers need in mind, and always appreciate your input and constructive criticism. Should any questions occur, please don't hesitate to ask your U-Turn dealer or the U-Turn team.

In order to provide you with the latest information on technical development and innovations at U-Turn, we ask you to complete the questionnaire attached. Please mail it to the following address:

U-TURN GmbH  
Paragliders and Kites  
Im Neuneck 1  
D- 78609 Tuningen  
Tel. +49 (0) 7464 /9891280  
Fax: +49 (0) 07464 /98912828  
Internet: [www.u-turn.de](http://www.u-turn.de)  
E-mail: [info@u-turn.de](mailto:info@u-turn.de)

Have fun and we wish you many flights on your new  
U-Turn LIGHTNING, your U-Turn Team



Please study this manual extensively, there is an obligation toward this recreational aircraft and its user manual to inform yourself about its specific features prior to its first use.

We composed this handbook, in order to make the handling of your new U-Turn LIGHTNING as safe and easy for you as possible.



# The U-Turn LIGHTNING

## **Usage**

The LIGHTNING is only designed for solo usage. The LIGHTNING is a light aircraft with a mass of less than 120 kg in the class of paragliders.

## **Motorised Paragliding**



We do not recommend to fly the U-Turn Hike&Fly as a Powered paraglider wing.

## Winching

Because of its excellent starting characteristics, the U-Turn LIGHTNING is well suitable for winching operations. Take the following points into account:

- maximum linetension for winching is 100kp.
- if not operating at your usual winch, get acquainted with the local procedures and get a good briefing by a local pilot.
- never winch the LIGHTNING with loads outside the allowable weight range.
- all involved persons, machines and accessories have to have the appropriate licenses, approvals, certifications for winching.


## Baseline and brakeline adjustment

The factory brake-line setting corresponds to 0-free travel plus 5 cm. It is recommended to adjust your brake line travel after the first flight to your personal preferences. Be aware not to adjust the brakes too short, otherwise the glider may fly with a little, but continuous applied brake pressure. This could be extremely dangerous during takeoff, flight and landing!

The afore mentioned factory brake setting allows for ample brake travel in extreme flight situations as well as for landing. At the same time it enables during flight at trim-speed a position of comfort for the pilots arms.

In no case the setup A, B and C main lines should be changed before the wing has been flown in the original setup.

Please also note that adjusting the height of the suspension to the hangpoints on the harness, changes the relative braking travel. When setting the adjustment it is to be made certain that both sides are symmetrical and that a permanent knot is used. The bowline works particularly well because of the fact that it weakens the lines the least with excellent slip resistance.



*Pfahlstich*



## Safety Precautions


We recommend the following precautions:

- Make your maiden flight in a familiar flying site and calm conditons.
- Test your U-Turn LIGHTNING only over water.
- In a „dynamic flight“ are not only you exposed to Hike loads but also the glider. Please don` t under estimate this.
- Only fly the LIGHTNING with at least one reserve parachute.
- observe and abide to the local aviation laws which rule in the respective country in question.
- Successful completion of appropriate training/schooling, having the needed knowledge as well as the actual flight experience are a prerequisite to operate your U-Turn LIGHTNING.
- The use of suitable, certified and in the respective country approved accessories (helmet, harness, reserve) is a requirement for the use of the U-Turn PASSION.
- Execute before every take off a thorough inspection of your equipment (topsail, undersail, ribs, especially the lines, carabiners, buckles, cloth speed system etc.) A flight with a tear in a glider or lines can be life threatening.
- Make sure that your flying gear is in good condition and all checks are done.
- Be aware that you as a pilot have to be in a physical and mental state to control each flight unimpaired. You have to concentrate completely on flying, in order to avoid potential distressing flight conditions. Most accidents are caused by pilot error.
- Never fly in close proximity to Hike voltage transmission lines, airports or motorways, over people or with lightning! You cold endanger your life and the physcial well being of yourself as well as third parties and at the same time act reckless and negligent. At nor circumstance should the minimum distance fall below 50m at any give time. At airports this minimum distance to main-tain is 5km..
- Inform yourself on the weather forecast and/or the predominating local weather conditions. Usethe U-Turn LIGHTNING only in wind strengths, in which you are able to control the wing for 100%. Do not use the U-Turn LIGHTNING, in wind with a great gust factor. Never use the glider with approaching thunderstorms or if probability of those of the development of thunderstorms is Hike. Land with thunderstorms approaching near immediately!
- The flying of aerobatics is generally forbidden and is dangerous. Unforeseen flight orientations can occur, which can spill out of control, arising the danger of overload on pilot and equipment.

**Ignoring one or several safety precautions can lead to a leisurely fun flight,  
turning into a fatal event.**




Glider description



## Risers


The A- and B-risers have a different colour to ensure positive identification at take off and during a B-stall descent.

The webbing in the risers of the U-Turn LIGHTNING consist of sturdy stretch resistant 12mm kevlar polyester webbing, in order to warrant a long-term stable trim.



## Speed System

The U-Turn LIGHTNING is equipped with a very effective foot actuates speed system



It increases the speed when applied with to approx. 12 km/h, depending upon wing size and pilot weight or surface loading.

Therefore it should not be activated in extreme flight situations or deactivate immediately when their occurring. All extreme flight attitudes (e.g. a-collapses) happen at accelerated speed more dynamically. Since the maximum acceleration is part of the safety behavior of the glider, it can happen that with some harnesses the speed bar to full speed cannot be used.

## Operation

This instruction manual only pays attention to those points of flying technique which are important for the U-Turn LIGHTNING. It is not meant to substitute a basic flying education in an approved flying school! If a flying education and the appropriate experience is missing, paragliding is dangerous to life. Of the LIGHTNING should be flown exclusively by experienced pilots.

## The Flight

### Take off

After the paraglider is unpacked and laid out in the shape of a horseshoe, the following points are to be considered:

- The paraglider should be laid out in such a way that when pulling up by the A-risers, the center lines are evenly, and earlier tensioned than those towards the wing tips. This ensures an easy and symmetrical inflation at launch.
- Take into consideration the wind direction when laying out, so that when pulling up into the wind, both sides of the paraglider can rise symmetrically.
- Ensure the risers are without twists, and the brake lines run freely through the pulleys to the trailing edge of the glider.
- No lines should pass underneath the sail. A line-over at take-off can have fatal consequences.
- The 5-point check shouldn't be forgotten of course.

The center of the glider in the U-Turn LIGHTNING is marked by the U-Turn-logo on the leading edge. It suffices to only hold the main A-risers in the hand. Since the U-Turn LIGHTNING has only a minor tendency to overshoot, it requires only minimal brake input during launch. If needed, directional corrections with the brakes should be undertaken only if the wing already is overhead, since too much brake input could drop the glider back. The other risers should, during take off, be left alone. With an even pull but overall light input only, the glider is to be inflated. Unlike other gliders, it is not necessary to inflate the U-Turn LIGHTNING with aggressive pulling or even fast running.

This is also true with little or no wind. Measured pulling up is the simplest and safest way to launch the U-Turn LIGHTNING. Once the pilot made sure that the glider is overhead and fully inflated, the final decision is made whether to take off. After some dynamic steps the pilot takes off.

### Turning

The U-Turn LIGHTNING has a normal agility and reacts directly and instantly to steering inputs. You can fly flat turns with little altitude loss by shifting of bodyweight. A combination of appropriate pull on the inner brakeline and shift of bodyweight is the best way for a coordinated turn. The Turn radius depends on the amount of pull on the brakeline.

At about 75% of brakeline travel, the U-Turn LIGHTNING increases bank significantly and performs a fast steep turn that can be continued to a diving spiral. The diving spiral has to be initiated and terminated slowly. The bank angle is controlled by increasing and decreasing the pull on the inner brakeline.



**Warning:** A rapid pull on the brakeline may cause a spin.


## Active Flying

The U-Turn LIGHTNING should be flown with light braking on both sides when there is turbulent air. An increase in angle of attack provides better stability. When entering heavy thermals or strong turbulences be mindful of that the canopy does not get behind the pilot. To avoid that, release the brakes a bit to get an increase in speed when entering the updraft.

If the canopy gets in front of the pilot when leaving a updraft or entering a downdraft the brakes have to be applied to counter that. Accelerated flight however is advisable when flying through downdraft zone. The U-Turn LIGHTNING is naturally very stable due to the way it`s constructed. Collapsing and deforming of the canopy can be avoided by active flying (as above mentioned) in turbulent air.

## Landing


Start your landing preparation at sufficient altitude. Due to its excellent flaring characteristics, the LIGHTNING is very easy to land. Glider in fairly normal to a straight- in final against the wind and get up in the harness early enough. According to the wind, the brakes have to be pulled firmly and dynamically, about one meter above ground, beyond the stalling point. If there is a strong headwind, be careful with the amount of braking. Don`t perform landings out of steep turns and big directional changes short prior landing, to avoid PLF.

 During a strong wind takeoff attempt, ground handling and landing the leading edge can hit the ground with Hike speed. Avoid this! Otherwise the ribs, the sewings or the fabric can be damaged.



## **Rapid Descent**

In any situation where you have to get down ASAP for different reasons (weather, extreme updraft, or other dangers,) there are a couple of techniques that are described in this chapter.

 **Caution:** The described manoeuvres stress you paraglider more than normal and should only be performed for practise or in a real emergency!

### **„Big Ears“**

Pull down simultaneously both designated outer A2-risers (by grabbing at or above the maillons), about 15-20cm to fold in the wingtips. The brake toggles are to be held in hand together with the pulled down A-risers. For additional stability and for an increased sinkrate the speedsystem should be actuated. The glider remains fully steerable by weightshifting and descents at a rate of 4-7m/s straight forward.

Once you release the A-risers, the folded wingtips reinflate automatically, if not, you may pump the brakes gently. „Big earing“ is due to the Hike wingload a very stable flight condition and well suited evine in turbulent air.

Please be aware that you reduce the trimspeed during „big ears“, but this can be compensated by applying speedbar. „Big earing“ in combination with weight shifting in order to get the glider to spiral dive, will achieve the Hikeest sink rate. This descent method is often taught in SIV training. Be mindful this exposes the glider to extreme loads, should one need to use this maneuver again we recommend an equipment inspection.

### **B-Stall**

Another very efficient descent method is the B-stall. It allows for a rate of descent of 6 to over 9 meters per second. Check the airspace under and behind you prior to initiating a B-Stall. To initiate it you hold the two B-risers above the lines carabiner. While holding the brakes in your hands at all times, pull the B-risers down progressively and symmetrically down to the shoulder to about chest level. Hold this position. Your sail will stop ! ying forward, partially empty, and stabilize itself overhead. During this the wing will fall back a little, which shouldn't tempt you to release the risers again. The glider would then shoot forward and oscillate vigorously. Only once the glider has stabilized overhead it is ok to exit the B-line stall. For this release the risers symmectrically into their original position.

We recommend no to simply let the risers snap shut as this puts a lot of pressure on the material. In the paragraph titled „advanced handling“ you can read what to do if you get caught unexpectedly in a stall.

## Advanced Handling


Even with its Hike stability and good flight characteristics it is possible that the LIGHTNING gets into an extreme flight condition due to pilot mistakes or turbulent air. To be prepared for such situations and able to handle them in a calm and superior manner it is best to take part in a flight safety course. Advanced manoeuvres may only be flown at sufficient altitude, in calm air and with professional supervision (i.e. during a safety course). Once again we mention that a rescuesystem is required by the law.


The following extreme manoeuvres can be either caused intentionally, by pilots mistakes or by bad weather conditions. Every pilot can get in such a situation! All mentioned extreme

manoeuvres are dangerous if they are performed without the appropriate knowledge or enough altitude or the necessary introduction. A wrong execution of these manoeuvres may have fatal consequences!

### Spiral Dive

Like a normal turn, it is very easy to get the LIGHTNING into a spiral dive. The spiral dive gets you a descent rate up to 20 m/s. To prepare oneself in case of, practise it in optimum conditions. The diving spiral gets the pilot down faster than other techniques and is therefore best suited for an emergency descent. They move down vertically within the airmass. Don't forget the G-forces when diving down, and take that into consideration before initiating a rapid descent.

 **Caution:** If initiation is too fast there is a danger of a spin, in this case release the brake and try a smoother initiation.

 **Caution:** The symmetric spiral is exclusively a maneuver for amusement. It's often recommended as a descent method, however we do not recommend to do so. This is because no spiral dive can be initiated in strong thermal conditions.

### Wingovers

The pilot has to perform right and left turns with increasing bank until the desired angle is reached. Collapsing wingtips is prevented by gently applying brake pressure in the up and/or downswing of the wingover.

### Full Frontal

A negative AoA caused by turbulences or the simultaneous pulldown of the A-risers by the pilot, results in a frontal collapse of the leading edge. The LIGHTNING comes out of a frontstall by itself very quickly. Smooth and symmetric applying of the brakes assists the opening of the canopy positively. Even, symmetrical, subtle pumping of the brakes can assist the reopening.



## Collapses

Even with its Hike stability and very responds well in turbulence, strong turbulences can cause the LIGHTNING to collapse. That situation is not really dangerous and clears itself automatically, without any further input required. To support the recovery, firmly apply brakes on the affected side and simultaneously steer opposite on the open side. When a large part of the canopy is collapsed be careful and smooth when applying opposite steering to avoid a complete disruption of airflow and entering a fullstall.

In case of larger deflations the counter steering is to be exercised with restraint / in moderation, in order not to completely interrupt the airflow to the positive side of the wing and spin the glider.

### How to avoid collapses

Single side collapses close to the ground are the number one reason for accidents with paragliders. To avoid them, or how to handle the situation when it happened, some tips and tricks from U-Turn test- and competition pilot Ernst Strobl:

The best way to avoid collapses upfront is the right choice of the paraglider. A lot of pilots fly a glider that is a little too hot to handle for them. So why don't you get a glider with a lower rating but in the end fly better and Hikeer in the updrafts and have a lot more fun and by the way be safer, too. To optimize the feeling for your glider on the ground, try the following:

Practice on the ground with the right wind at a suitable location. Slowly pull up the canopy and try to hold it up as long as possible without looking towards it. That is a good way to improve the feeling for your glider and is a prerequisite for „active flying“ (the key to avoid collapses). Very important is also a close look at the terrain. Watch for obstacles that could cause turbulences (buildings, trees, ...). On certain days, for example a freshly mowed meadow as landing field, could cause a lot of thermal activity. Fly very alert on a thermal active day. Watch your canopy, collapses most of the time, announce themselves. Light braking in turbulences mostly avoids a collapse. You should have already practised that on the ground. Should a collapse occur close to the ground don't always try to prevent a turn away. There is a danger when the braking on the open side is too strong, to lose the airflow on this side and stall the glider. Rather use the turn away motion to try to open the collapsed side.

Apply smooth braking on the open side, depending on the size of the collapse, and maybe a little pumping action. Some canopies open a lot better when the brakes are fully applied once on the according side, but that depends on the brakelines adjustment and your armlength. Wrapped lines are cleared by braking the opposite side at enough altitude and pumping the affected side a couple of times. Watch out for a possible stall. If that does not clear the situation, try to pull down the outer lines as much as possible. If you are too low for that, stabilize the canopy on the opposite side avoid turning away, and leave the lines like they are. Instead of any - risky manoeuvres rather concentrate on the landing. In the end one more advice in order to have all kinds of situations under control.

Visit a safety-training above water. There is no better way to practice the right behaviour than simulating a dangerous situation. Don't get caught off guard by your first collapse. In addition, during safety-training you can familiarize yourself with the particulars of your equipment and you gain confidence in your gliders as well as your own abilities.

Thus far the expert advise concerning collapses, by Ernst Strobl.



## Deep Stall

The U-Turn LIGHTNING is not stall sensitive. If in a stall, caused by overpulling on the brakes, the rear risers or a delayed B-stall exit, the release of the brakes or the rear risers, recovers the stall. Should the stall be caused by an extreme flight condition or configuration (i.e. takeoff weight too low), a symmetric forward push on the A-riser or step the speed system recovers the stall.


**Warning:** Practicing stalls should be done with enough safe altitude. Never apply asymmetric brakes during a stall, it could cause a spin. If the LIGHTNING in deep stall, one should only brake release the brake the glider is in front.


## Fullstall

To initiate a full stall, pull both brakes without a wrap slowly to the point of stall. As soon as the point of stall is reached, hold both hands down. The glider falls back. At point, under no circumstance should the hands let up or release the brakes. To recover from a full stall the canopy should be stabilized overhead and prefilled. For this slightly let up both brakes symmetrically. To exit completely, let up both brakes symmetrically and slowly in its entirety. With a correct symmetrical exit the glider returns swiftly, as soon as the glider shoots strongly forward, it must be checked by a brief brake input. An asymmetrical recovery is to be avoided, this could lead to falling into the glider.

## Negativ Turn

A negative turn/spin is initiated, when the pilot pulls the brake on one side fast and completely though the point of stall while letting the other side of the wing fly freely. With a negative turn the glider turns relatively fast around its center, while the inside flies backwards. In order to exist a spin, the applied brake released, where stalled side of the wing can pick up speed or one exit though a full stall, by braking the flying side into a stall also.

 **Warning:** The Spin and the Fullstall and unpredictable and dangerous flight attitudes and should only be executed in a safety training under guidance and never be intentionally executed. There is danger of riser twist. With a riser twist the brake lines can get blocked.


 **Warning:** The glider has been overloaded. Fullstalls and negative turns / spins as a descent method is dangerous, because a wrong exit, independent of glider type, can have fatal consequences.

## Emergency Piloting

In any situation where normal steering with the brakelines is not possible, the U-Turn LIGHTNING can be steered with the back risers easily. Turns can be flown with weightshift, however be mindful that the glider doesn't lock into a spiral.

## Transport and storage

When transporting the glider dont expose it to any liquids and has to be packed totally dry. Store the LIGHTNING always protected from UV radiation. Furthermore never store the wing together with acids or similar gods. A dry storage is very important!

 **Attention:** After a long storage period the glider must be checked!

## **Maintenance and Care**

Because U-Turn only uses Hike quality materials, your LIGHTNING will be airworthy for many years if you take good care. The aging of your LIGHTNING depends on the total flying time, the conditions you fly in, the amount of UV radiation it is exposed to and the intensity and quality of care. A couple of tips for maintenance and care:

Long lasting exposure to UV radiation and normal use stress the material

- Don't expose your glider to the sun when there is no need to
- Consider the choice of terrain where you lay out the glider for takeoff
- Assymmetrical and changing folding patterns prolong the lifetime of the material especially in the middle section.

Please take following points into consideration

- regular checks for damage
- no unnecessary bending
- lines after overloads (tree landing, water landing, etc.) for its strength and correct length to be checked and exchanged if necessary
- in case of changing inflight handling characteristics, the line have to be checked for their-correct length
- don't tie the brakelines on the grips if not needed, it weakens the lines

To clean the canopy use warm water and a soft sponge. If you use a detergent for hard stains, make sure that you rinse intensively afterwards. Never apply any chemicals for cleaning, they weaken the material and damage the coating. Store your glider at a dry and dark location away from any chemicals. After two years or 300 flight hours, whichever occurs first, your LIGHTNING has to be inspected by the manufacturer, in case of extreme use we are glad to do that earlier. Only you know about the condition of your glider. Should there be a need for any repairs they are to be done by the manufacturer.

## **Nature and environment friendly behaviour**

We ask you to perform our sport in a manner, that impacts nature and environment with minimum intensity. Please do not walk beside marked paths, don't leave any waste, please be not noisy and respect the sensitive biological equilibrium in the mountains. Especially at starting areas maximum care for nature is necessary. The synthetic materials your U-Turn glider is build must be depolluted appropriately. Please send your U-Turn glider at the end of its life-cycle back to U-Turn. We will take care for recycling and removal.

## FLight accessories

### Harness

All officially approved harness systems with mounting about the breast height are suitable for the LIGHTNING. The lower the mounting, the better is the steering by shifting of the bodyweight. U-Turn recommends the new IQ4 harness for its Hikeest level of safety and convenience. The positioning of the mounting also changes the relative brakedistance. If you have any questions about the usage of your harness with the LIGHTNING, ask your U-Turn dealer or directly contact U-Turn. We assist you in any possible way.

### Suitable Rescue System

It is required by law and absolutely necessary for safe operation of your paraglider that you always carry a rescue system with you. When choosing a rescue system, watch out that it is approved and suitable for the intended takeoff weight. With the innovative rescue systems of the SECURE-series by U-Turn light-weight, convenient and safe reserves are available. The SECURE rescues offer extremely short opening times and low sink-rates.



## **Assumption of Risk**

Flying the U-Turn LIGHTNING is inherent with certain dangers of bodily harm or even death of the user of this product or third party equipment. With the use of the LIGHTNING you assume all known and unknown risks and accept probable and improbable risks to injury. The dangers innate with the practice this kind of sport can be reduced by adhering to the warning notes in the manual, as well as the required attention to detail on each flight. The risks inherent to the sport can be reduced to a large degree, if one adheres both to the maintenance guidelines, which are listed in this operating manual, as well as using common sense.

## **Liability claim and renouncement of exclusion**

With the completion of the sale of a U-Turn LIGHTNING you express your consent with the following points of legal specifications:

### THE RENOUNCEMENT EXCLUSION OF ALL LIABILITY CLAIMS

deriving from the use the U-Turn LIGHTNING and or either components thereof, now or in the future, against the U-Turn GmbH and all other contracting parties, that could arise.

Releasing U-Turn GmbH and all other contracting parties of all liability claims concerning loss, damage, injury or expenses to you, your next of kin, relatives or any other user of the U-Turn LIGHTNING as a result could suffer. This includes but is not limited to lawful or contractual liability on behalf U-Turn GmbH and all other contracting parties as a result of the of production and processing the U-Turn LIGHTNING and all its components. With the occurrence of death or disability, all directives stated here come into force and bind their beneficiaries, next of kin, trustees, legal successors and/ or representatives. The U-Turn GmbH and all other contracting parties express no verbal or written representation and denial expressly that this was done, with exception of what is specified in and in the manual the U-Turn LIGHTNING.

## **Safety Advices and Liability**

This glider complies with EAPR, AFNOR (SHV and ACPUL) regulations, for the tested type, at time of delivery (see appendix). The operation of the glider is at your own risk. The manufacturer and the dealer don't take any liability for accidents and follow on damages. Please consider all safety notes, cautions and warnings for safe flying. Further, we assume that the pilot has the necessary certifications and that the legal limitations are being followed. Use of the equipment is at your own risk. Follow the safety instructions for a safe flight.

## **Release of Liability, Renouncement of Entitlement**

Hereby you declare, that you -prior to use of the U-Turn LIGHTNING- the U-Turn LIGHTNING user manual in its entirety, including directions and warnings, which are included in this user manual, have read and understood. Moreover to carry responsibility - prior to granting the use by a third party of U-Turn LIGHTNING - through transferring ownership temporary or permanently, for this other user to have read and understood the U-Turn LIGHTNING user manual in its entirety, including directions and warnings, which are included in this user manual.

-----  
Date

-----  
Signature first Pilot

-----  
Date

-----  
Signature second Pilot

-----  
Date

-----  
Signature third Pilot

**U-Turn cannot be hold responsible for any 2-year inspection and any repairs not performed by U-Turn or an U-Turn authorized dealer. Any checking or repairing performed by people not authorized by U-Turn will cause denial of any warranty!**

# Technical Data U-Turn LIGHTNING

PRODUCT PRESENTATION



## LIGHTNING INFOS



10,5



SKYTEX 27  
SKYTEX 36



## TECHNICAL DATA

LIGHTNING	XS	S	SM	M	L
Start Weight	50-80 kg	60-90 kg	75-100 kg	85-110 kg	100-130 kg
Flat Area	21,5 m <sup>2</sup>	23,5 m <sup>2</sup>	25,5 m <sup>2</sup>	27,5 m <sup>2</sup>	29,5 m <sup>2</sup>
Projected Area	18,16 m <sup>2</sup>	19,85 m <sup>2</sup>	20,54 m <sup>2</sup>	23,23 m <sup>2</sup>	24,92 m <sup>2</sup>
Flat Wingspan	11,16 m	11,67 m	12,16 m	12,63 m	13,08 m
Projected Wingspan	8,66 m	9,06 m	9,43 m	9,8 m	10,15 m
Flat AR	5,8	5,8	5,8	5,8	5,8
Projected AR	4,13	4,13	4,13	4,13	4,13
Chord: Center / Wingtip	2,378 / 0,590 m	2,486 / 0,620 m	2,590 / 0,646 m	2,689 / 0,670 m	2,785 / 0,695 m
V-Trim	39-40 km/h	39-40 km/h	39-40 km/h	39-40 km/h	39-40 km/h
V-Max	51-52 km/h	51-52 km/h	51-52 km/h	51-52 km/h	51-52 km/h
Bridle height	6,706 m	7,005 m	7,297 m	7,578 m	7,848 m
Nr. of Cells	50	50	50	50	50
Glider Weight	4,2 kg	4,4 kg	4,8 kg	5,2 kg	5,6 kg
Bridle length	219,6	229,9	239,7	249,2 m	258,3 m
Line Diameter	0,55/0,65/0,7/1,1 1,2/1,3/1,45/1,6mm	0,55/0,65/0,7/1,1 1,2/1,3/1,45/1,6mm	0,55/0,65/0,7/1,1 1,2/1,3/1,45/1,6mm	0,55/0,65/0,7/1,1 1,2/1,3/1,45/1,6mm	0,55/0,65/0,7/1,1 1,2/1,3/1,45/1,6mm
Speed System / Trimmer	Yes / No	Yes / No	Yes / No	Yes / No	Yes / No
Certification	No Certification	EN-B / LTF-B	EN-B / LTF-B	EN-B / LTF-B	EN-B / LTF-B
Certified standards and procedures	LTF 91/09 EN 926/1 & 926/2	LTF 91/09 EN 926/1 & 926/2	LTF 91/09 EN 926/1 & 926/2	LTF 91/09 EN 926/1 & 926/2	LTF 91/09 EN 926/1 & 926/2
Folding lines used for certification	No	No	No	No	No
Certification No.		EAPR-GS-7575/12	EAPR-GS-7574/12	EAPR-GS-7538/12	EAPR-GS-7564/12

Errors and omissions expected. Subject to change without notice. Reproduction in whole or in part without written permission of U-Turn GmbH is prohibited.

## COLORS




U-Turn offers special colors too. If you have questions about your LIGHTNING in special colors don't hesitate to contact your competence center or directly us. We are pleased to help.





# Installation manual U-Turn SoftLink

The SoftLinks by U-Turn are an extreme light opportunity to attach the risers to the lines. They are safe and easy to install




# Table of area loading and Color-Info

Lightning		Flächenbelastungstabelle / Surface load per square meter																TURN
Startgewicht Start Weight (kg)	50	55	60	65	70	75	80	85	90	95	100	105	110	115	120	125	130	
LIGHTNING XS	2,33	2,56	2,79	3,02	3,26	3,49	3,72	3,95	4,19	4,42	4,65	4,88	5,12					
LIGHTNING S		2,34	2,55	2,77	2,98	3,19	3,40	3,62	3,83	4,04	4,26	4,47	4,68	4,89				
LIGHTNING SM			2,35	2,55	2,75	2,94	3,14	3,33	3,53	3,73	3,92	4,12	4,31	4,51	4,71			
LIGHTNING M				2,36	2,55	2,73	2,91	3,09	3,27	3,45	3,64	3,82	4,00	4,18	4,36	4,55	4,73	
LIGHTNING L					2,37	2,54	2,71	2,88	3,05	3,22	3,39	3,56	3,73	3,90	4,07	4,24	4,41	

## Material Info U-Turn LIGHTNING


Lightning



# Material List U-Turn LIGHTNING

Lightning		Material list U-Turn		TURN	
Marking of components	Material / product name	Technical data / Dimesion weight / strenght	Producer		
Attachment loops	Nylon	7,2 g/m / Bruchlast 110kg / 13mm Breite	Kolon Industrial Co. Korea		
Accelerator lines	Nylon	Ø 4,0mm = Bruchlast 350 daN	Gin Gliders Korea		
Accelerator- brakeroll	GIN Rolle		Gin Gliders Korea		
Accelerator lock	Brummelhook		Gin Gliders Korea		
Brake attachment	Nylon	7,2 g/m / Bruchlast 110kg / 10mm Breite	Kolon Industrial Co. Korea		
Brake handhold	High Tanacity Polyester Yarn 22mm	25 g/m / 1000 kg breaking strength	Gin Gliders Korea		
Brake handhold attachment	High Tanacity Polyester Yarn 22mm	25 g/m / 1000 kg breaking strength	Gin Gliders Korea		
brake handhold fication	Press Button		Gin Gliders Korea		
Brake main line LIROS PPSL 200	Dynema Lines	1,8mm / 200daN	Rosenberger Tauwerke, Germany		
Lines: Look at Lineconfiguration	Liros / Edelrid		Rosenberger Tauwerke / EDELRID-Germany		
Riser attachment A / B	Liros CD 1800	10mm Dyneema Guriband min. breaking strength 1800kg	Rosenberger Tauwerke, Germany		
Riser attachment C	Liros CD 1000	7mm Dyneema Guriband min. breaking strength 1000kg	Rosenberger Tauwerke, Germany		
Belt direction	Stainless Steel	Ø 3,8mm / breaking strength 800kg	Ansung Precision CO. Korea		
Lines lock	U-Turn SoftLink L	Bruchlast 800kg	Gin Gliders Korea		
Top	Skytex 38 Dep.// Skytex 27	38 g/m <sup>2</sup> // 27g/m <sup>2</sup> PA 6.6	Porcher Marine, NCV, France		
Bottom	Skytex 38 Dep.// Skytex 27	38 g/m <sup>2</sup> // 27g/m <sup>2</sup> PA 6.6	Porcher Marine, NCV, France		
Rips, Profile (With Line-starting-point)	Skytex 32 hard finish	32 g/m <sup>2</sup> , PA 6.6 HT, HF	Porcher Marine, NCV, France		
Rips, Profile (Without Line-starting-point)	Skytex 27 hard finish	27 g/m <sup>2</sup> , PA 6.6 HT, HF	Porcher Marine, NCV, France		
V-Rips, V-Tapes	Skytex 32 hard finish	32 g/m <sup>2</sup> , PA 6.6 HT, HF	Porcher Marine, NCV, France		
Profilnose reinforcement	PPN - Nylon	2,2mm / 2,5mm Ø	Gin Gliders Korea		
Riser	High Tanacity Polyester Yarn 22mm	25 g/m / 1000 kg breaking strength	Techni Sangles, France		
Reinforcement povit point A/B/C/D	G 180	180 g/m <sup>2</sup>	Gin Gliders Korea		
sewing thread canopy	High Tanacity Polyester Yarn 150D/2	0,05 g/m <sup>2</sup> / 2,9 kg breaking strength	Amann & Söhne GmbH, Germany		
sewing thread lines	High Tanacity Polyester Yarn 150D/3	0,083 g/m <sup>2</sup> / 3,2 kg breaking strength	Amann & Söhne GmbH, Germany		

Line loop protection - Internal Dyneema core



## Lineplan

All lineplan can you order by U-Turn under  
info@u-turn.de

**Certification U-Turn LIGHTNING S**

**Certification U-Turn LIGHTNING S**

**Certification U-Turn LIGHTNING S**



**Certification U-Turn LIGHTNING S/M**

**Certification U-Turn LIGHTNING S/M**

**Certification U-Turn LIGHTNING S/M**

**Certification U-Turn LIGHTNING M**

**Certification U-Turn LIGHTNING M**

**Certification U-Turn LIGHTNING M**

**Certification U-Turn LIGHTNING L**

**Certification U-Turn LIGHTNING L**



**Certification U-Turn LIGHTNING L**

# Instruction leaflet for repairs and 2 annual Check





U-Turn GmbH  
Im Neuneck 1  
78609 Tuningen  
Germany

Tel: +49 (0)7464 / 9891280  
Fax +49 (0)7464 / 989128-28

## *Instruction leaflet for repairs and 2 annual Check*

Name:	Surname:
Adress:	Zip, City:
Land:	Telephone Number:
E-Mail:	
Paraglider type and Color:	Serialnumber:
Comments/ notes:	

- |   |   |
|---|---|
| <input type="checkbox"/> 2 annual Check                         | <input type="checkbox"/> Line Check incl. strength test |
| <input type="checkbox"/> Air permeability check                 | <input type="checkbox"/> Repair of the marked damage    |
| <input type="checkbox"/> Recall with sighting of the paraglider |   |



Please, pretend the repair-destitute place in the top sail and/or bottom sail.

# Line Order sheet



U-Turn GmbH  
 Im Neuneck 1  
 78609 Tuningen  
 Germany

Tel: +49 (0)7464/9891280  
 Fax: +49 (0)7464/989128-28

## LINE ORDER SHEET / BESTELLFORMULAR FÜR LEINEN

Name	
Adress / Adresse	
E-mail	
Telephone Number / Telefon Nummer	
Paragliding name / Gleitschirm Name	
Size / Größe	
Other / Sonstiges	

Serial Number / Serien Nummer: \_\_\_\_\_-\_\_\_\_\_-\_\_\_\_\_

Line ID / Bezeichnung	Quantity/ Stückzahl	Line ID / Bezeichnung	Quantity/ Stückzahl

## Business Replay Card

U-Turn GmbH  
Im Neuneck 1  
D- 78609 Tuningen



Name : \_\_\_\_\_

First name: \_\_\_\_\_

Street: \_\_\_\_\_

Zip code/ City: \_\_\_\_\_

Telephone: \_\_\_\_\_

E-Mail: \_\_\_\_\_

Paraglider type: \_\_\_\_\_

Serial number: \_\_\_\_\_

Date of purchase: \_\_\_\_\_

DealershipP: \_\_\_\_\_

Tested by: \_\_\_\_\_

Flying hours: \_\_\_\_\_

Paraglider since: \_\_\_\_\_

Miscellaneous: \_\_\_\_\_

Yes, I would like to get the newsletter by E-Mail



## **Maintenance manual**

as developer and manufacturer for paragliders, harnesses and rescue parachutes

**Englisch Rev. 1.0 Stand: April 2014**

Copyright ©

2014 by U-Turn GmbH, all right preserved. No part of this publication may be reproduced or developed further on in any way without written approval of the U-Turn GmbH

Text: Stefan Preuss

Text and Graphics: Ernst Strobl

All technical details in this manual have been carefully checked by U-Turn. However we like to mention that we don't take any liability for possible mistakes, neither in legal responsibility, nor in liability cases that derive from mistakable details. We preserve the right to change this manual in any way to achieve technical improvements.

## **Topic of the inspection and reinspection intervals**

Regular inspection according to aircraft inspection ordinance for standardized evaluated gliders. For school gliders after 1 year, aircraft for recreational use after 2 years. Tandem gliders for commercial purposes annually, non commercial use every 2 years to be inspected. The inspection shall take place in the aforementioned intervals, or no later than 150 hours. Ground handling needs to be included in the sum of flight hours. Generally speaking; in the case any abnormal flight behavior, the manufacturer should be informed and the canopy, if necessary, sent in for inspection.

### **Who may inspect/test?**

Besides the manufacturer or the by him approved person or instance is authorized the owner of the glider to warrant the bi-annual inspection and only in compliance with pre-requisites set forth.

### **Individual personal prerequisites for the inspections**

Personal prerequisites for the inspection of individually owned solo gliders for recreational use only:

- Holder of a valid unrestricted license for paragliders or equivalent accredited license.
- An adequate orientation in the operation by the manufacturer. For this a 3 month formation with the manufacturer is necessary.
- If a glider was tested for personal use exclusively, then its use by a third party is not allowed.

Individual personal prerequisites for the inspection of gliders, RG,GZ, used by third parties or for tandem purpose:

- A for the testing prescribed professional training.
- A vocational activity in the production or maintenance of GS, RG, GZ or one of a technically similar nature. Of which 6 month within the last 24 in a manufacturing operation recreational free flight aircraft.
- An at least 2 week, subject to charge, relevant training course at the operation of the manufacturer.
- An applicable orientation for each type of device, which is to be refreshed annually.

### **Necessary equipment and documentation**

- Gauge, preferably Kretschmer (brand) with manual.
- Bettsometer with manual.
- Maintenance directions by manufacturer.
- Original materials and -spare parts, as well as original material-record for the device.
- Assertion of airworthiness for the device.
- Airports device identification tag (see manual).
- Line length table (see manual).
- Line length logs (if available).
- Inspection log (collecting main) to the documentation.
- Lighttable for visual inspection of the reserve.

## **During the inspection the following steps are to be taken in:**

### **Positive identification of the device:**

Positive identification of the aircraft (Type, size, etc.) on the basis certification seal or placard..

- Are the pertinent manufacturer documents available?
- If certification seal and/ or placard are in place, are they readable and correct?
- If not so: Please obtain from manufacturer or dealer in question.

The determined values / modification are to be noted in an inspection log!

### **Inspection of the reserve parachute**

Before packing the reserve parachute this is to be checked by packer. If the parachute was deployed for a rescue, then it is subject to an inspection. If a folded reserve parachute is re-packed again a deployment check is to be staged, to be determined is if the force for deployment is between a minimum of 3kg and maximum of 6kg.

### **Testing of the topsail, undersail, seams, reserve parachute of**

#### **holes and tears**

The topsail and undersail of both paragliders as well as reserve parachutes must, for each cell (paragliders) and each gore (parachutes), from the leading edge to the trailing edge, submitted to the following checks. If in one of the following attributes anomalies are discovered, the glider is to be sent in to the manufacturer for inspection.

- Check for holes smaller or larger tears, deformations and abraded areas.
- Deficiencies in the coating, other aberrations in the canopy like e.g. old repairs.
- With reserve parachutes a light-talbe is to be used for an inspection for holes, tears and deformations.

#### **Abrasion and deformaties**

With large and critical abrasion and deformations, the entire cell panel in question must be replaced by the manufacturer. The determined values/modifications are to be noted in the testin log!

#### **Testing of the ribs**

Visual inspection of the chambers (from the leading to the trailing edge) whether the stitching in the seams, cell partition ribs and reinforcements are in good shape, thus without tears, deformations, abrasions or damage of the coating.

With torn ribs, defective, loose or missing stitching in the seams the glider must be returned the to the manufacturer or authorized inspection operation. The determined values/modifications are to be noted in the inpection log!

## **Check of the tear resistance**

To be conducted with the Bettsometer at the following points (B.M.A.A. approved patent number GB2270768 Clive of bed Sails)

The test sequence is to be inferred from the operating instruction the Bettosometer.

- In both the top and undersail where the A-lines connect, push a needle-thick hole and check the tear resistance.
- The limit value of the measurement is determined at 500g, and a tear width of fewer than 5mm.

The determined values / modifications are to be noted in the inspection log!

## **Porositycheck of the canopy**

At all following measuring points the air porosity has to be more than at least 20 sec. (by Kretschmer).

At smaller air permeability values the paraglider must be returned to the manufacturer.

Measuring points: The porosity measurements by the Kretschmer measuring method (please consider operating instruction) are to be conducted at the following points on the canopy check on both under and upper sail.

- Center cell approx. 20-30cm back from leading edge
- 3rd Cell off center both to the left /right approx. 20-30cm back from leading edge
- 10th Cell off center both to the left /right approx. 20-30 cam back from leading edge

The determined values / modifications are to be noted in the inspection log!

## **Connection parts**

Check of the webbing and maillons

- are there abrasions, buckling, tears, strong signs of wear obvious?
- Is all the stitching fast and firm?
- Is the accelerator running free and intact?
- Are brake toggle attachments still firmly sewn on?
- Are the maillons corrosion free, are the sleeves of the gates free moving on the thread?

Measure under a load of 5 kg. The determined values are to be compared with the specifications from the EAPR-Technical data sheet. Allowable variations are to be inferred from the manufacturer directions. If the webbing or parts thereof are defective, spare parts are to be ordered from the manufacturer and replace the defective parts with original parts. The determined values/modification are to be note in the inspection log!



## Lines

Test of the line tensile strength:

Line selection: select a middle, lower cascade of the A, B and a C- lines as well as if available a middle A and B upper cascade, and stress test for tensile strength testing device on their tensile strength.

Tension velocity of the tension cylinder:  $v=30\text{cm/min}$

Tear/tensile strength values:

the determined values/modifications are to be noted in the inspection!

 **Attention:** Each size (line diameter) is to be assigned a fixed value.

In case the lines cannot withstand the indicated load/stress or pass tensile strength test, all other lines must also be changed. If the checked lines fulfill the test criteria, only those are replaced by new lines.

All replaced lines are to be marked in the proximity of the maillon (seam) with a black felt marker pen and noted in the inspection log with the date of the exchange and the logged of hours of flight time of the glider. During the next test for tensile strength an original line, neighbouring the replaced line is to be sampled. The various line diameters are allocated a minimal Sewing length!

## Check of the line length and line attachments

Bottom cascade, upper cascades and brake lines for, breaks, abrasions, visual check. First the A-lines, then B. etc.

- Are all lines adequately sewn and attached to the line attachments?
- Is the sheathing of the lines even are exactly?
- Are all loops, knots, seams in good shape?
- Are there any abrasions present?

Measuring the line lengths:

- The lines must be measured with a load of 5 kg, in order to obtain comparable results. The relevant line lengths are in the technical data sheet of the uster manual.
- The measurement takes place in accordance with DHV method, from the maillon to the canopy (inclusive attachment loop at the sail).
- The numbering takes place from the stabilo toward the center. Measuring the opposite facing of the wing can under same conditions also be conducted by a symmetry comparison.
- The results are again noted the inspection log and should be compared side by side to line lengths of the EAPR technical data sheet. The tolerance in deviation of these values should not exceed more than  $\pm 1,5\text{cm}$
- If a line is defective, it is to be exchanged immediately. Please acquire the identification reference marking of the line from the line plan, order from the manufacturer and replace accordingly or have it replaced.

The determined values / modifications are to be noted in the inspection log!

## **Occasional check of trim and adjustment**

Before a test flight a visual inspection of the canopy and lines is to be conducted with the glider laid out as well as pulled up inflated.

In particular attention should be paid to the length of the brake lines with the canopy inflated. Only if all doubts are cleared concerning faulty adjustment of the brake lines, a check flight may be conducted.

## **Description of the materials and technical data**

See manual of your paraglider.

### **miscellaneous**

- All measurement and repair work at paraglider and rescue system must be documented completely in the inspection log.
- When packing or repacking the reserve parachute, special attention is to be paid to the particular packing directions of the manufacturer! See rescue / reserve equipment manual.
- With the exchange of parts or component modules only original materials or original replacement parts may be used!
- With sewing work the original sewing pattern is to be kept, patching and thread material of same strength and quality as original!
- The inspection survey and/or test log must with be signed, complete with place and date!
- The period for recordkeeping is 4 years.

## **Completed check very important!**

Before you perform any checks and/or repairs yourself on your glider, we ask to read you the following pages carefully. You inform yourself hereby about prerequisites and conditions of a done in person bi-annual inspection.

- According to new DHV regulation, the customer (Glider-owner) can conduct the 2-yearly check of the canopy with the help of the inspection directions and all necessary testing equipment and documents in person on his own responsibility. In addition the wing does not have to be sent in to the manufacturer.
- The 2-yearly check may only be conducted by the glider owner personally, if he fulfills the prerequisites, or an inspection station authorized by the manufacturer. Inquire therefore with the manufacturer on authorized inspection stations.
- The owner of the canopy must be aware of the responsibility, which he takes with a self conducted 2-yearly check of the glider. The self performed 2-yearly check is only legally effective, if this is acknowledged after the check with date, name (in capitals) and signature on or beside the placard.
- Reserve equipment re-packing interval in accordance with DHV: Every 4 months a repacking is required. Allowed period of operation: 8 years, afterwards up to 12 years with an annual check
- About insurance-legal consequences of your self performed 2-yearly inspection you should inform with your insurer in a timely fashion.
- An inspection is valid only if the inspection log is completely filled out. Inform also about possible revisions of the inspection directions with the manufacturer before the inspection.
- **Important:** If the necessary efforts for the maintenance inspection cannot be carried out (required equipment and documents), should the canopy be sent in to the manufacturer.
- For paragliders, harnesses and reserve parachutes, which are checked, controlled, repaired, packed or repacked, test-flown and/or other maintenance work, by none U-turn authorized personnel forgot any guarantee and or warranty!
- All maintenance work must in be accordance with the maintenance specifications of the operation manual and the special maintenance directions of the manufacturer and the publications of the IHB to be conducted.
- With any abnormal appearances during the performance of maintenance is the technical manager to be informed, who has to decide on how to procede.
- With the replacement of parts or component modules only original materials or original party-may be used!